FREE PLAY MODE

ADVANTAGES OF FREE PLAY MODE


- Allows you to choose an application without the keyboard
- Allows you to create a selection of applications
- Allows students to choose games (autonomy)
- Promotes democracy within the group


SITUATIONS IN WHICH FREE PLAY MODE CAN BE USED

- Warm-up time
- Free station during individual evaluations
- Free play time
- Reward
- Open house at the school
- Activities by other school stakeholders (after-school care, individualized support)
- Etc.

CHOOSING APPLICATIONS

1. Click on the settings gear icon.
2. Select **“Free play mode”**.
3. Select or deselect applications. Please note that only part of the Lü application catalog is available in free play mode.





USING FREE PLAY MODE

1. Click on the basketball icon on the left.
2. Select a game using a ball or your hand.
3. To exit the application, use the **“Escape” + “OK”** keys on the controller.

